



# CL610/CL615 - Installation Template



Important!

When printing templates, check your print settings to make sure that the template is printed at 100% of the actual size.

Once printed, check the measurements on the template with a ruler before drilling your door or cabinet.

[Open Template PDF](#)

IT-600ML-V01

© 2019 Codelocks Ltd. All rights reserved.