













# Installation Instructions

## DL4000 Series Mortise Deadlock

If Thumturn is not used, disregard those steps pertaining to its application.



**Corbin Russwin**

Corbin Russwin Architectural Hardware  
225 Episcopal Road Berlin, CT 06037 USA

FM-8C (617332000) Rev 12/00