

Cylinders



4031-3071
Cast Iron Cylinder Assembly

- Non-handed
- Standard

Covers



4030-72MC
Metal Cover

- Non-handed
- Standard

Installation Accessories



4030-18T
Plate

- Required for top jamb mounting where head frame is less than 2-1/4" (57 mm) or flush ceiling condition exists
- Requires 1-1/2" (38 mm) minimum



4030-18PA
Plate

- Required for parallel arm mounting where top rail is less than 5" (127 mm), measured from the stop
- Requires 1-3/4" (44 mm) minimum



4030-30
CUSH Shoe Support

- Provide anchorage for fifth screw used with CUSH arms where reveal is less than 3-1/16" (78 mm)



4030-61
Blade Stop Spacer

- Lowers parallel arm shoe to clear 1/2" (13 mm) blade stop



4030-62A
Auxiliary Shoe

- Requires a top rail of 7" (178 mm)
- Replaces -62PA for parallel arm mounting of regular arm with some overhead holder/stop
- Optional



4030-419
PA Flush Panel Adapter

- Provides horizontal mounting surface for PA or CUSH shoe on single rabbed or flush frame



4030-62PA
PA Shoe

- Required for parallel arm mounting

Arms

**4030-3077**

Regular Arm

- Non-handed
- Mounts hinge side or top jamb
- P4031 closer includes PA SHOE, 4030-62PA is required for parallel arm mounting

**4030-3077LD**

Light Duty Arm

- Non-handed
- Mounts hinge side, top jamb or parallel arm (62PA required)
- Optional

**4030-3077L**

Long Arm

- Non-handed
- Includes LONG ROD AND SHOE, 4030-79LR for top jamb mount with deep reveals
- Optional

**4030-3049**

Hold-Open Arm

- Non-handed
- Mounts hinge side, top jamb or parallel arm (62PA required)
- Hold-open adjustable at shoe
- Optional

**4030-3049L**

Long Hold-Open Arm

- Non-handed
- Includes LONG HEAD AND TUBE, 4030-3048L for top jamb mount with deep reveals
- Optional

**4030-3077EDA**

Extra Duty Arm

- Non-handed
- Extra duty arm features solid forged steel main and forearm for potentially abusive installations
- Optional

**4030-3049EDA**

Hold-Open EDA Arm

- Handed
- Arm, provides hold-open function adjustable at shoe
- Optional

**4030-3077CNS**

Cush-n-Stop® Arm

- Non-handed
- Solid forged steel main arm and forearm with stop in soffit shoe
- Optional

**4030-3049CNS**

Hold-Open CUSH Arm

- Non-handed
- Provides hold-open function with templated stop/hold-open points
- Handle controls hold-open function
- Optional

**4030-3077SCNS**

Spring CUSH Arm

- Non-handed
- For abusive applications
- Features solid forged steel main arm and forearm with spring loaded stop in the soffit shoe
- Optional

**4030-3049SCNS**

Spring HCUSH Arm

- Non-handed
- For abusive applications
- Features solid forged steel main arm and forearm with spring loaded stop in the soffit shoe
- Handle controls hold-open function
- Optional